


# GENERA.



## G1/F1

Creation made reliable.

# G1/F1

Desktop. Clean. Automated.

The G1/F1 brings the GENERA workflow and automation to your desktop. It is compatible with the GENERA validated material library and uses a cartridge-based material unit to store the resin. The G1/F1 utilizes the GENERA shuttle technology for a clean and safe workflow. The F1 uses a mercury flash bulb for curing the parts in an inert atmosphere.

The parts are cleaned in two cleaning tanks specially designed for secure use with IPA.

The whole workflow is RFID tracked.

The material unit, combined with a material cartridge, ensures clean and safe handling. The material unit is automatically opened by the G1 and automatically dispensed. An integrated recoater helps to mix the resin within the resin vat to ensure consistent print results. The vat can be heated and tracks low resin levels as well as the film lifetime. After the printing process the G1 automatically stores the part in the shuttle. The part is then automatically post-processed by the F1.

## HARD FACTS

### Print volume

@70  $\mu\text{m}$

x: 134 mm

y: 76 mm

z: 150 mm

### Wavelength

385 nm DLP

### 2K Resolution

(1920x1080)

**Glove free process with shuttle technology and automated post-processing**




**Material unit with cartridge for easy and secure resin handling**

**Active carbon filter for odor reduction**

**Post-curing in inert atmosphere**

**Documentation and traceability by RFID tag and database**





SYSTEM COMPONENTS G1/F1

- 1 Human Machine Interface (HMI) with machine control, part preview and printing progress
- 2 Automatic handling system for platforms
- 3 Material unit and cartridge
- 4 2K 385 nm DLP light engine with 70 µm pixel size
- 5 Glove-free process with RFID-tagged transport-shuttle for fully automated post-processing
- 6 Human Machine Interface (HMI) with machine control, part preview and status progress
- 7 Automatic handling system for platforms
- 8a, 8b Glove-free process with RFID-tagged pre- and postwash-container with Integrated magnetic stirrer for fully automated washing
- 9 Post-curing chamber
  - o High-power mercury flash bulb
  - o Inert atmosphere
  - o Part drying
- 10 Overflow protection



alphacam GmbH  
Erlenwiesen 16  
D-73614 Schorndorf  
Tel.: +49 (0) 71 81 92 22 - 0  
info@alphacam.de

alphacam austria GmbH  
Handelskai 92, Gate1 / 2. OG / Top A  
A-1200 Wien  
Tel.: +43 (0) 1 36 19 600 - 0  
info@alphacam.at

alphacam swiss GmbH  
Zürcherstrasse 14  
CH-8400 Winterthur  
Tel.: +41 (0) 52 - 262 07 - 50  
info@alphacam.ch



alphacam.de

.at

.ch